

WiFi Instructions

1. Press the power button to activate the hotspot



2. Locate the network name (SSID) and password on the back of the hotspot.

3. On your device, select **ContraCostaLibraryWiFi** from the list of networks. Enter the password **WiFi4@LL**

4. Up to 10 devices can use the hotspot at the same time. A full charge takes 3-5 hours.

WiFi Instructions

1. Press the power button to activate the hotspot



2. Locate the network name (SSID) and password on the back of the hotspot.

3. On your device, select **ContraCostaLibraryWiFi** from the list of networks. Enter the password **WiFi4@LL**

4. Up to 10 devices can use the hotspot at the same time. A full charge takes 3-5 hours.

WiFi Instructions

1. Press the power button to activate the hotspot



2. Locate the network name (SSID) and password on the back of the hotspot.

3. On your device, select **ContraCostaLibraryWiFi** from the list of networks. Enter the password **WiFi4@LL**

4. Up to 10 devices can use the hotspot at the same time. A full charge takes 3-5 hours.

Indicaciones para el uso de la red WiFi

1. Presione el botón de encendido para activar el hotspot.



2. Localice el nombre de la red (SSID) y contraseña en la parte posterior del hotspot.

3. En su dispositivo, seleccione **ContraCostaLibraryWiFi** de la lista de redes. Ingrese la contraseña **WiFi4@LL**

4. El hotspot puede ser usado hasta por 10 dispositivos al mismo tiempo. Una carga completa tarda de 3 a 5 horas.

Indicaciones para el uso de la red WiFi

1. Presione el botón de encendido para activar el hotspot.



2. Localice el nombre de la red (SSID) y contraseña en la parte posterior del hotspot.

3. En su dispositivo, seleccione **ContraCostaLibraryWiFi** de la lista de redes. Ingrese la contraseña **WiFi4@LL**

4. El hotspot puede ser usado hasta por 10 dispositivos al mismo tiempo. Una carga completa tarda de 3 a 5 horas.

Indicaciones para el uso de la red WiFi

1. Presione el botón de encendido para activar el hotspot.



2. Localice el nombre de la red (SSID) y contraseña en la parte posterior del hotspot.

3. En su dispositivo, seleccione **ContraCostaLibraryWiFi** de la lista de redes. Ingrese la contraseña **WiFi4@LL**

4. El hotspot puede ser usado hasta por 10 dispositivos al mismo tiempo. Una carga completa tarda de 3 a 5 horas.