

Coolpad Surf Mobile Hotspot

Turn on

1. Press the **Power** button on the mobile hotspot until all four indicators momentarily flash blue.
2. Wait for the **Network** and **Wi-Fi** Indicators to come on, one at a time.
3. When the Network and Wi-Fi icons light up blue, the Wi-Fi connection is enabled.

Turn off

1. Press the **Power** button on the mobile hotspot until all four indicators momentarily flash blue.
2. When all four buttons go dark, the Network and Wi-Fi connections have been disabled.

Connect to the Mobile HotSpot

To connect your Wi-Fi enabled device to your Mobile Hotspot for internet access, follow these steps:

1. Make sure your Mobile Hotspot is turned on.
2. Select the Wi-Fi Network Name (SSID).
3. Enter the Wi-Fi Password.

Charging Your Mobile Hotspot

1. Connect the microUSB end of the USB cable to the USB port on your device.
2. Connect the other end to the travel adapter.
3. Connect the travel adapter to an electrical outlet to fully charge your device.

Note: You can also charge the device by connecting it to a computer with the USB cable.

Device Layout



LED indicators: Display network signal, Wi-Fi, battery charge, and mobile data status.

| Indicators | Description |
|------------|--|
| Network | Displays your current network status. Green light indicates good network connection; yellow light indicates poor network connection; red light indicates no network connection, no SIM card, or no service |
| Wi-Fi | Indicates when Wi-Fi is connected. |
| Battery | Displays your current battery status. Solid green light indicates the battery level is 40%-100%, solid yellow light indicates the battery level is 16%-39%, and solid red light indicates the battery level is less than 15%; when the device is charging, the indicator will flash red when the battery level is below 15%, will flash yellow when the battery level is 16%-39%, and will flash green when the battery level is 40%-100%. |
| Data | Indicates when your data allotment is running out. The indicator will flash red when the data usage is higher than 75% of the monthly data plan set, will flash yellow when the data usage is 51%-75%, and will flash green when the data usage is below 50%. You will need to configure your monthly data plan and tick the "Auto Disconnected" box on Web User Interface first. |